


MU 250 + LV 250 / MU 250 + MM 250

Quick Guide – Version 1.0



- UHF band
- Frequency Response: 30Hz-20KHz
- Balanced and unbalanced output
- 1x Bodypack transmitter + 1 lavalier microphone (MU 250 + LV 250) + Receiver
- 1x Handheld microphone (MU 250 + MM250) + Receiver
- DC 12V Receiver, 2xAA Batteries Transmitter

UHF wireless system

SAFETY INSTRUCTIONS

- Use the closed QR code to download the last user manual version from our website.
- Don't use this device close to the water or high humidity places. Clean only with dry cloth.
- Don't install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by AUDIOMUSIC
- Unplug this device during lightning storms or when unused for long periods of time.




MM 250 MIC25001



LV 250 MIC25002

MU 250 + LV 250 / MU 250 + MM 250

Guía rápida – Versión 1.0



- Banda UHF
- Respuesta en frecuencias: 30Hz-20KHz
- Salida Balanceada y desbalanceada
- 1x emisor de petaca + 1 micrófono lavalier (MU 250 + LV 250) + Receptor
- 1x micrófono emisor de mano (MU 250 + MM250) + Receptor
- DC 12V Receptor, Pilas 2xAA en emisores

Sistema inalámbrico UHF

INSTRUCCIONES DE SEGURIDAD

- Use el Código QR adjunto para descargar la última versión del manual de usuario desde nuestro sitio web.
- No use este dispositivo cerca del agua o zonas altamente húmedas. A la hora de limpiarlo, utilice un paño seco.
- No instale el dispositivo cerca de ninguna fuente de calor o fuego tales como calefactores, estufas o incluso amplificadores que produzcan calor.
- Proteja el cable de ser pinzado o pisado.
- Únicamente utilice accesorios especificados por AUDIOMUSIC
- Desenchufe el dispositivo si no va a ser utilizado en largos periodos de tiempo.



MM 250 MIC25001



LV 250 MIC25002