

BLC 1 is a wallmount controller for the BlueLine receivers.

- It can control the audio input source.
- It can control the audio level.
- It adds an auxiliary input through mini-jack connector.
- It has remote port to connect a BlueLine receiver.
- The maximum distance between BLC 1 and the BLR must be 5 m.


## CONNECTION (version MKII only)

Use a STANDARD Ethernet cable to connect the BLC 1 to the correct input (CONTROL) in the receiver (BLR2 MKII, BLR2 LITE MKII, BLR2 A PLUS MKII)

## IMPORTANT!!!

If your are using the BLC 1 in an installation with the original BlueLine Digital devices with white enclosure, please, remember that the link cable IS NOT STANDARD. Check the following diagram to see the manufacturing instructions.





BLC 1 es un controlador mural para los receptores BlueLine.

- Puede controlar la fuente de entrada de audio
- Puede controlar el nivel de audio.
- Añade una entrada auxiliar mediante conector mini-jack
- Dispone de un puerto remoto para conectar el receptor BlueLine.
- La distancia máxima entre BLC 1 y un BLR debe ser de 5 m.

## CONEXIÓN (Sólo versión MKII)

Use un cable Ethernet STANDARD para conectar el BLC 1 a la entrada correcta (CONTROL) en el receptor (BLR2 MKII, BLR2 LITE MKII, BLR2 A PLUS MKII)

## IMPORTANTE !!!

Si está usando el BLC 1 en una instalación con los dispositivos BlueLine Digital de chasis blanco, por favor, recuerde que el cable de enlace NO ES STANDARD. Verifique el siguiente diagrama para ver las instrucciones de fabricación.

