




MWCA 402 white

Quick Guide – Version 1.0



6.5" Woofer+ 1" tweeter
2x40W power output.
Wifi/Bluetooth receiver
Remote controller
MUZO Player app (suggested)

2x40W active ceiling speakers with Wifi/BT functionality

SAFETY INSTRUCTIONS

- Use the closed QR code to download the last user manual version from our website.
- Before connecting the device, check your country safety regulations.
- Don't use this device close to the water or high humidity places. Clean only with dry cloth.
- Don't install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Make certain that the equipment is always installed so that is cooled and can't overheat.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by MARK.




50MWA402



MUZO Player app (Available free on iOS & Android)

MWCA 402 white

Guía rápida – Versión 1.0



6.5" Woofer+ 1" tweeter
Potencia de salida 2x40W
Receptor Wifi/Bluetooth
Mando remoto
App MUZO Player (Sugerida)

Altavoces de techo de 2x40W con funcionalidad Wifi/BT

INSTRUCCIONES DE SEGURIDAD

- Use el Código QR adjunto para descargar la última versión del manual de usuario desde nuestro sitio web.
- Respete las instrucciones de seguridad de su país cuando instales este dispositivo
- No use este dispositivo cerca del agua o zonas altamente húmedas. A la hora de limpiarlo, utilice un paño seco.
- No instale el dispositivo cerca de ninguna fuente de calor o fuego tales como calefactores, estufas o incluso amplificadores que produzcan calor. Asegúrese de que, una vez instalado el dispositivo, esté en un lugar fresco y seco.
- Proteja el cable de alimentación para no ser pisado o manipulado.
- Únicamente utilice accesorios especificados por MARK



50MWA402



App MUZO Player (Disponible gratis para iOS y Android)