

## Appendix.

# MAB 40 A v 2.1 Bluetooth Switch OFF


User Manual – Version 2.1




# MAB 40A v2.0. HOW TO POWER OFF THE BLUETOOTH MODULE.

If you have the latest version of MAB 40A and you want to power off the bluetooth module, you need to link two pins in the connector that appears in the picture.

This action makes the bluetooth not accesible from any device.




Link the holes marked BT and off by solderring them. In the picture you can see both holes marked with clamp tips.




# MAB 40A v2.0. CÓMO DESCONECTAR EL MÓDULO BLUETOOTH.

Si tiene la última versión de MAB 40A y quiere desconectar el módulo bluetooth, tiene que puentear los dos pines en la placa del dispositivo que aparece en la imagen.

Esta acción hace que el bluetooth no sea accesible desde ningún dispositivo.



Puentee los agujeros marcados como BT y off soldándolo. En la imagen puede ver ambos agujeros indicados con las puntas de una pinza.





Av. Salar nº14 Poligono. Ind. L'Alteró. Silla 46460 VALENCIA-SPAIN

Tel: +34 961216301

[www.equipson.es](http://www.equipson.es)